

STRUCTURE OF MICROCARD (BASIC INSTRUCTIONS)

A02 = How to use the microcard	1	2	3	4
A01 = Structure of microcard			SIS	
B01 = Trouble-shooting chart	-A-	***X*	X*XXX	XXXXX XXXXX *XXXX X
	-B-	*XXXX	XXXXX XXXXX XXXXX XXX	
	C-	XXXXX	XXXXX XXXXX XXXXX XXX	
	D-	XXXXX	XXXXX XXXXX XXXXX XXX	
	E-	XXXXX	XXXXX XXXXX XXXXX XX	
	F-	XXXXX	XXXXX XXXX	
	G-	XXXXX	XXXXX XXXX	
	H-			
	J-			
	K-			
	L-			
	M-			
N01 = Service Information	-N-	*XXXX	XXXXX XXXXX XXX	*X XX*
		12345	67890 12345 67890	12345 678
			1	2
				Index
				N28 = Table of contents and impressum

- 1 = Special features
- 2 = Safety and precautionary measures
- 3 = Test equipment and tools
- 4 = Installation position of components

- a. Read from left to right.
- b. Title of coordinate (appears on each coordinate).

E16	Product/components/test step	
	Coordinate	

c. Limits of section

==>	<==	<==	=> <=
Start	Mid-section	End	One-page section

A01		=> <=
-----	--	-------

HOW TO USE THIS MICROCARD

Trouble-shooting instructions for
System Car Pilot
Descriptions, photos, terminal designations
and special features refer to vehicle:

BMW 524 td

These instructions are detailed trouble-shooting instructions and apply to the Car Pilot in any passenger-car vehicle.

A02		=> <=
-----	--	-------

SPECIAL FEATURES

The Car Pilot has been installed in certain passenger cars since mid-1987.

2. Rapid diagnosis chart

The following rapid diagnosis chart makes it possible for the experienced expert to quickly check the system with a commercially available multimeter and 2 test leads KDZS 0004 or KDZS 0005.

The contents of this chart are limited to the following:

- * Sequence of test steps
- * Test instructions and test specifications (readings on multimeter).
- * References to coordinates of the respective detailed testing and trouble-shooting program.

If detailed information and instructions are necessary, always proceed according to the trouble-shooting program starting on Coordinate C1.

Requirements for testing:

- * Check customer complaints (check operation of Car Pilot according to operating instructions)
- * Electrical system (fuses, battery voltage) O.K.
- * Plug connected to magnetic-field sensor


The ignition must be off before disconnecting plug-in connections.

General introduction

Since mid-1987 Bosch has been supplying a retrofittable navigational system that can be installed in passenger cars.

The navigational system consists of the following components:


- * Navigational system with integrated keyboard and display unit
- * Electronic earth's-magnetic-field sensor
- * Distance-impulse transmitter
- * Polar-coordinate measuring instrument



- 1 = On/off switch
- 2 = Upper pressure point of rocker for increasing numbers
- 3 = Lower pressure point of rocker for reducing numbers
- 4 = Key for moving menu cursor
- 5 = Enter key for inputs and actions
- 6 = Selector switch US/metric

The Car Pilot is operated with these 5 keys. With the rocker it is possible to change numerical values so as to make them higher or lower. A time-control facility allows the desired numerical value to be reached quickly.


Changeover from the metric to the imperial (US) system of dimensions is accomplished by means of a sliding switch which is let into the base of the housing.



The information is output via a liquid-crystal display on which the data are displayed with seven-segment displays, characters and symbols (see picture).

Menu arrows point to the selected function.

The "Calibration" function (cal), which is not listed in the menu, is selected by pressing the rocker and the menu key simultaneously.



263 / 206

A = Distance transmitter
 B = Display unit
 C = Magnetic-field sensor
 D = Interference consumer
 E = Diode *

1 = Term. 15
 2 = Term. 31
 3 = Signal from retrofitted distance transmitter
 4 = Signal from installed distance transmitter
 5 = Term. 30
 6 = Term. 15 or term. R




7 = 4-pin connecting lead to magnet-field sensor, possibly with an extension
 8 = Consumer switch
 9 = ON/OFF signal from interference consumer
 10 = Term. 58b
 11 = Instrument lighting
 12 = Term. 58

*Diode required only for Reed-contact distance transmitters not connected to a feedback-controlled electrical-system voltage.

CIRCUIT DIAGRAM




RAPID DIAGNOSIS CHART

Item	Fault	Casue of fault How to rectify	Display on Car Pilot	Coor- dina- tes
1	Keys do not function	Replace Car Pilot display unit	—	B17
2	Partial failure of display	Call up check menu: Car Pilot in compass menu Press top rocker, MENU, bottom rocker, QUIT	All segments appear on display	B17
3	Angle display not functioning or defective	<ul style="list-style-type: none">*Magnetic-field sensor defective Call up fault display*Power supply (break in lead to sensor)*Unit not (no longer) calibrated*Magnetic-field sensor mounted on tailgate and poor ground connection Corrective action: ground strap from body to tailgate	Fault number 1 Fault number 4 or 5 Fault number 1 Fault number 1	B18
4	Car Pilot has major navigational errors	<ul style="list-style-type: none">*Additional distance impulses with lights "ON", low battery voltage or interfering ignition impulses Call up check menu Distance-impulse display: Switch on lights*Loose contact on distance sensor Call up check menu Drive same route	Watch display Watch display	B27





RAPID DIAGNOSIS CHART (continued)

It- em	Fault	Cause of fault How to rectify	Display on Car Pilot	Coor- dina- tes
4	Car Pilot has major navi- gational errors	*Loose contact on magnetic- field sensor Call up check menu	Fault number 4 or 5	B19
		*Unit not or poorly calibrated		
		Make note of distance and angle reference numbers with vehicle stationary. Compare with distance and angle reference numbers in angle report.	Incorrect distance or angle reference number	B23 C05
		Drive in a circle. If still poor, then calibration of distance and angle reference numbers		
		*Internal defect in Car Pilot	Fault number on display 7, 8 or 9	B21
		Call up check menu and call up faults		
		*Interference consumer not calibrated with unit or break in cable	Fault number 3	B19
		Perform new calibration trip (drive in circle) with interference consumer		
		*With sensor in luggage compartment and metal objects moving in luggage compartment (tool box).		
		Secure tool box or other moving parts.		





RAPID DIAGNOSIS CHART (continued)

Item	Fault	Cause of fault How to rectify	Display on Car Pilot	Coordinates
4	Car Pilot has major navigational errors	<p>*With sensor in passenger compartment and e.g. moving magnetic mascot e.g. on mirror</p> <p>Remove moving magnetic part</p> <p>*In case of trips over 300 km long and with system off</p> <p>Drive in circle again</p>	<p>————</p> <p>————</p>	C05
5	Night-time reduction not controllable	<p>*Display unit incorrectly connected</p> <p>Check connection of night-time reduction and correct</p>	<p>————</p>	B17
6	Arbitrary changeover to night-time reduction	<p>*Voltage drop across body</p> <p>Connect diode between brake switch and stop lamp. Anode of diode to switch</p>	<p>————</p>	B17
7	Radio interference	<p>*Shielding of swan-neck has poor ground, or the cable length of the shielding has been changed.</p>	<p>————</p>	B17



RAPID DIAGNOSIS CHART

Item	Fault	Cause of fault How to rectify	Display on Car Pilot	Coordinates
7	Radio interference (continued)	<p>Make good ground connection (directly on to body metal). Leave cable length of shielding unchanged</p> <p>*Joint power supply to Car Pilot and radio</p> <p>Provide separate power supply</p> <p>*Length of leads at term. 30, term. 15 and term. 31 too long</p> <p>Correct lengths of leads</p> <p>*Unfavorable installation of antenna e.g. windshield antenna or active antenna on front side of vehicle</p> <p>Installation of antenna at rear of vehicle</p>	<div></div> <div></div> <div></div> <div></div> <div></div>	B17
8	Magnetic-field sensor drops off	<p>*Adhesive bonded at incorrect temperature (below 18°C) or bonding location dirty.</p> <p>Replace adhesive film under magnetic-field sensor. Make sure that base is free of grease and that ambient temperature is above 20°C.</p>	<div></div>	C05



RAPID DIAGNOSIS CHART

Item	Fault	Cause of fault How to rectify	Display on Car Pilot	Coordinates
9	Car Pilot cannot be calibrated	<p>Check installation position of magnetic-field sensor</p> <p>* In compass menu, select display of magnetic-field strength.</p> <p>Slowly drive in a circle with vehicle.</p> <p>If strength is not constant, i.e. if the display jumps while driving in a circle, the installation location is unsuitable.</p>	<p>_____</p> <p>_____</p> <p>Values on the display must rise or fall steadily between the minimum and maximum values.</p>	C07


TEST EQUIPMENT AND TOOLS

Multimeter	ETE 014.00	0 684 101 400
or e.g. Pontavi		Commercially available
2 test leads, e.g.		KDES 0002

For production reasons:
continued on the following
coordinate.


INSTALLATION POSITION OF COMPONENTS

The display unit of the Car Pilot is in the passenger compartment in the field of vision of the driver.




The magnetic-field sensor is in the previously established most favorable installation position for the system, e.g.

- * Vehicle roof
- * Luggage-compartment lid (inside)
- * Rear parcel shelf
- * Above interior mirror on windshield or on rear window at the top



Distance-impulse transmitter

- * Supplied distance-impulse transmitter in speedometer shaft
- * Otherwise vehicle's own distance impulses from transmitters in the vehicle e.g. Reed contacts, photoelectric light barrier, Hall sensor or induction-type transmitter.



TROUBLE-SHOOTING

* How to use the self-diagnosis

This system has a self-diagnosis feature.

Therefore, whenever testing, start with the self-diagnosis.

How to activate the self-diagnosis is described on Coordinate B01.

The self-diagnosis/test table starting on Coordinate B05 contains fault indication, cause of fault, test instructions and coordinate references for direct trouble-shooting. If, during the self-diagnosis, no fault is indicated and the customer complaint is still not remedied, continue trouble-shooting with the trouble-shooting chart on B09.

SELF-DIAGNOSIS

The system contains a SELF-TEST as well as a FAULT INDICATION

SELF-TEST

The system is able to test itself. During operation, however, it is not possible for all functions constantly to be checked. For this reason, the self-test has been sub-divided.

The following are constantly monitored:

- * Magnetic-field sensor and
- * if applicable, quality / correctness of magnetic-field calibration.

For production reasons:
continued on the following
coordinate.

SELF-DIAGNOSIS

Each time the system is switched on, the test is performed for

- * read-only memory (EPROM).

Each time term. 30 is connected, the

- * random access memory (RAM) is tested.

In addition, it is also possible for the test menu to be called up in order to test the

- * non-volatile random access memory (EEPROM) and the
- * distance sensor.

Test conditions:

- * Vehicle stationary

- * Switch on system

- * System in compass menu




Press the following four keys in the correct order:

- * Top rocker, MENU, bottom rocker, QUIT

After the keys have been pressed in this sequence, the menu arrow disappears and the symbol CHEC flashes on the seven-segment display.

After the "Quit key" has been pressed, all segments appear. The segments remain in the display until the "Quit key" is pressed again.

Now the EEPROM is tested. (Data are kept) in case the system is not switched off during the test. If the test is successful, the system then shows CORR or a fault number (fault with highest priority).



SELF-DIAGNOSIS (CONTINUED)

After the display has been acknowledged (press QUIT key), the distance-impulse display is shown. With the vehicle stationary, the display shows "0000".

Distance impulses are now produced:

- * By turning the sensor shaft
- * By short-circuiting the distance-signal cable to ground
- * Or by driving the vehicle
- * Turning the wheel on which the sensor is situated
- * Poor ground connection
- * Vehicle lighting switched on (night-time reduction activated) and unfavorable routing of cables, the sum of the impulses measured is indicated.

The "QUIT" key is used to reset to 0; the Menu key is used to abort the test.

Resetting the system to its original condition is possible if, before pressing "QUIT", the bottom rocker is pressed and is held down for approx. 5 seconds together with the QUIT key.




"BYE" flashes on 7-segment display.

Caution: After pressing "QUIT", the entire system is now changed into virgin condition; this means that EEPROM and RAM are erased. BYE display no longer flashes. Switch off system and switch on again

Then, in any case, perform a new calibration trip.

FAULT INDICATION

Various system-internal faults can be indicated. With the exception of faults 1, 2 and 3, which are indicated only after driving in a circle, after a calibration menu has been run, the fault number is indicated in the left-hand number of stages and "Err" is indicated on the 4-digit display.



SELF-DIAGNOSIS (CONTINUED)

Fault-indication table

Fault number	Cause of fault	Component	Test instructions with test specifications	Test step/ Coordinate
1	Full circle not driven	Magnetic-field sensor	Repeat driving in a circle	C05
2	Unfavorable installation position for magnetic-field sensor Unsuitable place for calibration trip (disturbing iron parts, street on incline)	Magnetic-field sensor	Check installation position of magnetic-field sensor again. Magnetic-field strength on display unit should not be greater than 50 A/m for one rotation of the magnetic-field sensor. Repeat driving in circle on horizontal location, not near large iron parts (tank installations etc.).	C05 C05
3	Consumer was switched on/off when driving in a circle	Consumer	If applicable, repeat driving in a circle without consumer and then switch consumer (i.e. SWITCH ON or OFF when asked to do so). Vehicle must be stationary.	C05
4	Magnet-field sensor produces nonsense readings	Magnetic-field sensor	Occurs usually when system has been re-connected to battery. To rectify, switch off system and then on again. If fault still present, fault in wiring harness or magnetic-field sensor defective.	C05
5	Magnetic-field sensor not connected, open circuit or loose contact in connecting lead between magnetic-field sensor and display unit	Magnetic-field sensor	Car Pilot in calibration menu. Disturb magnetic-field sensor with magnet. Then the old value (before disturbance) must appear on the display in A/m. The angle display does not change in the calibration menu.	C05

SELF-DIAGNOSIS (CONTINUED)

Fault-indication table

Fault number	Cause of fault	Component	Test instructions with test specifications	Test step/ Coordinate
6	Not occupied	_____	_____	_____
7	EEPROM fault	Display unit	Fault indicated in check menu. Replace display unit.	B17
8	RAM fault	Display unit	Fault indicated in check menu. Disconnect term. 30/re-connect. Call up check menu. If fault present, replace display unit.	B17
9	ROM fault	Display unit	Fault indicated in check menu. Replace display unit.	B17

TROUBLE-SHOOTING CHART

Customer complaint (fault symptoms)
The below-listed fault symptoms may be due
to one or more faults.

1. No display on Car Pilot.

2. One or more segments on Car Pilot not
being energized.

3. Cursor on Car Pilot cannot be moved
with Menu key.

4. Quit key not functioning.

5. Number of stages cannot be increased
or reduced with rocker.

Trouble-shooting					Coordi- nates
*				No power supply term. 30 (fuse defective)	B17
*				No power supply term. 15 or ground	B17
	*			Display unit defective	B17
	*	*	*	Keyboard defective	B17
*				Display defective	B17
	*			Non-abortable function called up e.g. calibration trip	B17
		*		Non-QUIT function called up or not pressed long enough (in navigation menu). Stage 0 or 99 selected	B17

B11



TROUBLE-SHOOTING CHART (CONTINUED)

Customer complaint (fault symptoms)
The below-listed fault symptoms may be due
to one or more faults.

6. Kilometer display on unit does not decrease
as vehicle moves toward destination.

7. After input, system shows nonsense
readings.


8. Compass points in the wrong direction
and turns with direction of travel.

9. Linking of different stages not
functioning.

10. Display test not functioning.

Trouble-shooting					Coordi- nates
*				Distance transmitter defective	B23
	*			Magnetic-field sensor installed wrong way up	C05
		*		Display unit defective	B17
*				Stage not activated (no arrow indication)	A09
*				Vehicle moving away from destination (opposite)	A09
	*			Stages are linked. Rosette input not possible.	B17
	*	*		Stages have not been programmed in continuous manner.	B17
	*			US selector switch in wrong position	A05
		*		9th stage of trip has not been programmed	B17
*				Vehicle has Reed-contact transmitter that is not connected to feedback- controlled combination voltage.	B23

B12



TROUBLE-SHOOTING CHART (CONTINUED)

Customer complaint (fault symptoms)
The below-listed fault symptoms may be due to one or more faults.

11. Self-test cannot be called up.
12. Distance changes when vehicle is stationary and headlamps are on.
13. Vehicle lighting on, lighting potentiometer in min or max position. Display lit brightly.
14. Vehicle lighting off, display dark at times.
15. Radio interference.
16. System cannot be calibrated (fault 2).

Trouble-shooting					Coordi- nates
*				Select compass menu and switch system on/off.	B17
*				Poor ground connection (system and distance transmitter not to common ground). Lead term. 31 too long.	B17
	*			Brightness pot defective, poor contact.	A13
		*		High voltage drop across ground on body.	A13
			*	Shielding not directly connected to vehicle metal	A13
			*	Shielding has been shortened or lengthened	A15
			*	Vehicle has windshield antenna.	A15
			*	Unsuitable installation location (Magnetic-field sensor).	C07
			*	Unsuitable calibration location.	C07

For production reasons:
continued on the following
coordinated.

TROUBLE-SHOOTING ACCORDING TO TEST STEPS

* C o n d i t i o n s

- * Check customer complaints
(Check operation of Car Pilot according to operating instructions).
- * Electrical system (fuses, battery voltage) O.K.
- * Car Pilot installed according to installation instructions.
- * Both calibration trips performed.

When performing detailed trouble-shooting starting on Coordinate B17, go through the test steps one after the other.

Only if fault is indicated, proceed with the trouble-shooting in the right-hand column.

For production reasons:
continued on the following
coordinate.

Test step 1

Check display unit:

- * Disconnect term. 30 from display unit and re-connect.
- * Call up test menu.

To do this, (after switching on and before any other key is pressed) the four keys

"top rocker, MENU, bottom rocker, QUIT"

must be pressed and released again in precisely this order. For this, the system is in the compass menu.

The symbol CHEC flashes on the seven-segment display.

Press Quit key; all display elements now appear on the seven-segment display. After viewing, press Quit key again; the symbol CHEC again appears for approx. 2 seconds.

In these 2 seconds the EEPROM is tested. If the test is successful, the symbol Corr appears on the display unit; otherwise, the corresponding fault number appears. If nothing appears on the seven-segment display, or if a fault number is indicated, proceed according to the trouble-shooting on the right-hand side.




Trouble-shooting - test step 1

- * Check lead from term. 15 to display unit term. 5.
- * Check lead from term. 30 to display unit term. 4.
- * Check lead from term. 31 to display unit term. 2.

Eliminate open circuit or contact resistances on the leads.

If a fault number is indicated, continue on next page.

After replacing the display unit, it is necessary to perform a complete calibration trip (distance and angle).



Continued on next picture page

Trouble-shooting - test step 1 (continued 1)

Fault-indication table

Fault number	Cause of fault	Component	Test instructions with test specifications
1	Full circle not driven	Magnetic-field sensor	Repeat driving in a circle
2	Unfavorable installation position for magnetic-field sensor Unsuitable place for calibration trip (disturbing iron parts, street on incline)	Magnetic-field sensor	Check installation position of magnetic-field sensor again. Magnetic-field strength on display unit should not be greater than 50 A/m for one rotation of the magnetic-field sensor. Repeat driving in circle on horizontal location, not near large iron parts (tank installations etc.).
3	Consumer was switched on/off when driving in a circle	Consumer	If applicable, repeat driving in a circle without consumer and then switch consumer (i.e. SWITCH ON or OFF when asked to do so). Vehicle must be stationary.
4	Magnet-field sensor produces nonsense readings	Magnetic-field sensor	Occurs usually when system has been re-connected to battery. To rectify, switch off system and then on again. If fault still present, fault in wiring harness or magnetic-field sensor defective.
5	Magnetic-field sensor not connected, open circuit or loose contact in connecting lead between magnetic-field sensor and display unit	Magnetic-field sensor	Car Pilot in calibration menu. Disturb magnetic-field sensor with magnet. Then the old value (before disturbance) must appear on the display in A/m. The angle display does not change in the calibration menu.

Fault-indication table

Fault number	Cause of fault	Component	Test instructions with test specifications
6	Not occupied		
7	EEPROM fault	Display unit	Fault indicated in check menu. Replace display unit.
8	RAM fault	Display unit	Fault indicated in check menu. Disconnect term. 30/re-connect. Call up check menu. If fault present, replace display unit.
9	ROM fault	Display unit	Fault indicated in check menu. Replace display unit.

Test step 2

Checking the distance signal:

Switch on ignition
Switch on display unit
* Call up test menu

To do this, (after switching on and before any other key is pressed) the four keys

"top rocker, MENU, bottom rocker, QUIT"

must be pressed and released again in precisely this order.

For this, the system is in the compass menu.

The symbol CHECK flashes on the seven-segment display.

Press Quit key; all display elements now appear on the seven-segment display. After viewing, press Quit key again; the symbol CHEC appears again for approx. 2 seconds. In these 2 seconds,

the EEPROM is tested. If test is successful, the symbol CORR appears on the display unit; otherwise, the fault number appears.

By pressing Quit, you come to the distance-impulse display. The display shows 0000 with the vehicle stationary (bottom picture).

Trouble-shooting - test step 2:Switch off ignition

1. Check retrofitted distance-impulse transmitter
0 355 540 ..

* Switch on display unit.
Connect blue/red lead of distance-impulse transmitter to multimeter (voltage measurement).




Move vehicle very slowly.

If pointer on instrument deflects, distance-impulse transmitter is O.K.

* Otherwise, perform voltage measurement on the two other leads of the distance-impulse transmitter.

Set value: 0 V or U Batt.

If, despite supply voltage being applied, distance-impulse transmitter does not supply any distance impulses, replace the distance-impulse transmitter.



Continued on next picture page

TEST STEP 2 (CONTINUED 1) (TEST SPECIFICATIONS AND OPERATING INSTRUCTIONS)

Test step 2 (continued 1))

Move vehicle; the impulses occurring must now be counted on the display.

The display can be reset with the Quit key.

The test can be aborted with the Menu key.

Distance impulses detected?

N>

Trouble-shooting - test step 2 (continued 1):

Check vehicle-specific distance transmitters:



- * Connect voltmeter to distance-transmitter leads
- Measuring range 16V
- * Switch on term. 15
- * Move vehicle by one wheel revolution

1. Induction-type transmitter

- * During the movement of the vehicle, the voltage does not fluctuate between approximately 0 V and 12 V
- * Switch off terminal 15
- * Measure again on distance transmitter
- Measuring range = 0.2 V
- * Move vehicle
- Brief reading on voltmeter while vehicle is moving

If the reading is not briefly visible on the voltmeter, distance transmitter is defective.

Replace defective distance transmitter



Continued on next picture page

TEST STEP 2 (CONTINUED 2) (TEST SPECIFICATIONS AND OPERATING INSTRUCTIONS)



Test step 2 (continued 2)

With lights on, no distance impulses are detected with the vehicle stationary.

Trouble-shooting - test step 2 (continued 2)

- * Vehicle ground and distance-transmitter ground not connected to the same ground point.
- * Shielding not connected to ground.
- * Vehicle with Reed-contact transmitter:

Transmitter not connected to stabilized supply voltage e.g. 5V or 10V.



Continued on next picture page

Continued on next picture page

V


Trouble-shooting - test step 2
(continued 3)

2. Reed-contact transmitter

- * During testing, the reading on the voltmeter fluctuates between approximately 0 V and 12 V
- * Repeat test at the transmitter pins.
Switch off terminal 15
On the measuring instrument, switch from voltage measurement to resistance measurement
- * Move vehicle
Reading on ohmmeter between 0 Ω and greater than or equal to 1 k Ω

If no reading on ohmmeter,
distance transmitter is defective.

Replace defective distance
transmitter



V

Continued on next picture page

V

Trouble-shooting - test step 2
(continued 4)3. Hall or optical transmitter


- * During testing, the reading on the voltmeter fluctuates between approximately 0 V and 12 V
- * Repeat test at the transmitter pins.
Switch off terminal 15
On the measuring instrument, switch from voltage measurement to resistance measurement
- * Move vehicle
Reading on ohmmeter between 0 Ω and greater than or equal to 1 k Ω
- * While the vehicle is being moved, the reading remains at greater than or equal to 1 k Ω

If reading on ohmmeter less than 1 k Ω , distance transmitter is defective.

Replace defective distance transmitter

V

Continued on next picture page



Test step 3

Check magnetic-field sensor:

- * Switch on display unit (after term. 30 on, wait 1 min).
- * Select compass with menu key
- * Press Quit key for 5 sec
- * "HELP" appears on display
- * Press Quit key

No fault number appears

Trouble-shooting - test step 3

Fault 5
Switch off ignition


- *Check 4-pin connecting lead from magnetic-field sensor to display unit. If lead is extended, also check plug-in connector.

Eliminate open circuit or contact resistances at the leads or plug-in connectors.


- *Remove magnetic-field sensor
- *Supply magnetic-field sensor externally with voltage with voltage stabilizer (top picture).
- *Connect voltmeter R₁ greater than or equal to 20 k Ω /V according to test circuit
- *Apply 5 V or 0V alternately at input SU. Turn sensor through 360° (voltage change approx. 1V)

If voltage is not within the required tolerance range, replace the magnetic-field sensor.
If magnetic-field sensor is O.K., replace display unit.


After replacing the magnetic-field sensor or the display, it is necessary to perform a complete calibration trip.



263 / 192



263 / 195



263 / 207

Continued on next picture page

Test step 3 (continued)

Check installation position of magnetic-field sensor:

- * Switch on display unit (after term. 30 on, wait 1 min).
- * Select compass with menu key.
- * Press top rocker and hold down; at the same time, press key for moving menu cursors. Display shows flashing cal.
- * Press Quit key; the magnetic-field strength is indicated.
- * Slowly drive vehicle in a circle. Values on the display must fall or rise steadily between minimum and maximum values.
- * If fall/rise not steady, i.e. if the display jumps while driving in a circle, the installation position is unsuitable.

Value moves continuously in one direction.

Trouble-shooting – test step 3 (continued 1)

Check installation position of magnetic-field sensor again. Repeat driving in circle on horizontal location, not near large iron parts (tank installations etc).




TABLE OF CONTENTS

Section	Coordinates
Structure of this microcard.....	A01
How to use this microcard.....	A02
Special features.....	A03
General introduction.....	A04
Circuit diagram.....	A07
Rapid diagnosis chart.....	A09
Test equipment and tools.....	A19
Installation position of components.....	A21
Trouble-shooting.....	B01
How to use the self-diagnosis.....	B01
Trouble-shooting chart.....	B11
Trouble-shooting according to test steps.....	B16

For production reasons:
continued on the following
coordinate.

IMPRESSUM

(c) 1988 Robert Bosch GmbH
Automotive Equipment - After-Sales Service
Department for Technical Publications KH/VDT
Postfach 50, D-7000 Stuttgart 1.
Published by: After-Sales Service
Department for Training and Technology
(KH/VSK). Press date: 01.1988.
Please direct questions and comments
concerning the contents to our authorized
representative in your country.
This publication is intended only for the
BOSCH After-Sales Service Organization, and
may not be passed on to third parties
without our consent.
Microfilmed in the Federal Republic of Ger-
many. Microphotographie en République Fédé-
rale d'Allemagne.